

Soccer Goal Anchoring System Instructions

Anchor Placement

1. Four anchors should be used per goal, one in each corner.
 2. To aid in placement, the included chains should be placed under the goal before driving the anchors into the ground.
 3. Ideally, anchors should be placed no more than four inches away from the outside of the frame of the goal.
 4. Be careful to not place anchors in the field of play.
 5. Drive the anchor into the ground using the anchor impact tool.
-

Anchor Impact Tool

1. Chuck the tool into an impact driver with ½” drive.
 2. Place the tool over the top of the anchor and align the anchor perpendicular to the ground.
 3. Operate impact drill, at a controllable speed, in the clockwise direction to drive the anchor into the ground.
 4. Drive anchor until the tool makes contact with the ground, making sure that the eyelet is not buried.
-

Attaching the Chains

1. If not done already, lift up goal and place chains underneath in each corner where the anchors are placed.
 2. Feed one end of the chain through the eyelet of the anchor.
 3. Wrap the other end of the chain around the frame of the goal.
 4. Use the connector link to attach the two ends of the chain.
-

Removing the Anchors

5. Undo the chain connector link of the chain, and remove chain from anchor.
6. Using the Anchor Impact Tool, operate impact driver in the counter clockwise direction to remove the anchor from the ground.
7. Lift up goal to remove each of the chains.